

ATARI MUSIC CONSTRUCTION SET™ REFERENCE CARD

GETTING STARTED

1. **TO LOAD:** Start your disk as you would any other. NOTE: Owners of Atari XL computers must hold down the **OPTION** key while turning the computer on. You may stop holding the key down when the Electronic Arts logo appears on the screen.
2. **TO BEGIN:** Press **RETURN** when the program finishes loading. For information about how to use the on-screen hand to build, play and play with music, see the inside of this card. (If you wait a few seconds instead of pressing **RETURN** immediately, the music already on your disk will begin playing. Press the **SPACEBAR** to move the program ahead to the next piece. Press **RETURN** to begin using the program.)

MCS DISK MUSICAL TABLE OF CONTENTS

<u>FILENAME</u>	<u>(Actual name and composer)</u>
CANON	(Canon in D Major by Johannes Pachelbel)
BUMBLE	(Flight of the Bumblebee by Rimsky-Korsakov)
INVENT	(Two Part Invention No. 8 by J.S. Bach)
TURKEY	(Traditional)
NEW	(Load this whenever you are constructing music and want to erase what you have done and start over.)

Please note that due to space limitations on the Atari disk, the SCALES file (see page 10 of the manual) was eliminated.

Music adapted and arranged by Douglas Fulton. Special thanks to Greg Riker for his work on the instrumental sounds.

TO CONSTRUCT MUSIC AND USE THE OTHER CONTROLS

To pick up notes, etc. so you can drag them onto or off the musical staves at the top of the screen, simply point at whatever you want to pick up and press **RETURN** or the button on your joystick.

To move the hand, use your joystick or Control/cursor (arrow) key combinations. Pressing **RETURN** or the joystick button again will set down whatever you're carrying, wherever you're pointing.

You turn controls on and off in the same way — pointing at the Piano Icon for instance and pressing the button or **RETURN** will cause the computer to begin playing whatever music is in the display. Pressing **RETURN** or the button again will cause it to stop.

IMPORTANT NOTE: If you only want to use one staff, use the top one. Your music will not play if the bottom staff is used alone. (For additional troubleshooting information, see If You Hear a Beep and The Time Signature Control and Beat Counter sections elsewhere on this card.)

TO CHANGE YOUR CONTROLS

You may also control the program with an Atari Touch Tablet or a Koalapad. Simply turn on the Plug icon. (It's on the lower right, just below the Disk icon.) Then press the **SPACEBAR** to make different options appear and press **RETURN** to select the one you want.

In addition to on-screen hand control, The Plug icon will present you with two other sets of choices: 1) musical range and voice number, 2) printer type. Choosing the four voice, four octave option in the second set cuts the bottom octave from your MCS range and causes every note to be played as though it were written one octave higher. In general we recommend using the 3 voice, 5 octave option (and would like to extend special thanks to Greg Riker for his help in making sure that MCS would produce the highest possible tone quality and pitch accuracy from Atari computers.)

For information about what to enter if you want to print your music, see the How to Print Your Music section elsewhere in this card.

TO PLAY MUSIC

To play a piece of music you've constructed or loaded, turn on the Piano. As the music scrolls by, the notes will sound when they pass through the area above the small triangular play head (located just above the whole note). If you want to skip ahead or go back to hear a passage again, use the Arrow icons on either side of the Piano to scroll backwards and forwards through the piece. Turning on Home (just below the Piano) sends you back to the piece's beginning.

LOADING AND SAVING MUSIC


To load the music already on the MCS disk, turn on the Disk icon (it's just above the Plug), then type LOAD and the name of the selection you want (LOAD BUMBLE, for instance) and press **RETURN**. When the red disk drive light goes out, press **RETURN** again.

To save music to another disk, place that disk in the drive, then type SAVE followed by whatever name you want to use (it can be up to 8 characters long) and press **RETURN**. When your drive stops, remove your files disk, put the MCS disk back in the drive and press **RETURN** again. To load music from your files disk, follow the same procedure but type LOAD instead of SAVE.

IMPORTANT NOTE : Before you use a files disk for the first time, you must format it. To do that, simply put the disk in the drive, then type FORMAT and press **RETURN**. You may use this command anytime you're using your MCS program without disturbing the music in memory.

To see a list of what you have saved on your files disk, type CATALOG and press **RETURN**. You can save at least 20 pieces on a disk.

CUT AND PASTE



Turn on the scissors, place them over a measure and press the number key on the keyboard for the number of measures you want to cut. Pressing **3** for example will cut out the measure you're on and the next two measures to the right of it. If you try to cut a group of measures with more notes than the Cut and Paste buffer can handle, you'll hear a beep and the command will not be executed.

To put down copies of the last group of measures you cut into the buffer, turn on the paste pot, place it over the measure which you'd like the buffer music inserted in front of, then press the button on your pointing device or **RETURN**.

SPEED, VOLUME AND SOUND CONTROLS



The five gauges in the center let you control playback speed, volume and sound quality by using the hand to move the gauge markers up and down. Point to the center of a gauge in the region of a marker, and each push of a button or **RETURN** will move that marker one notch closer to the end of the finger.

SPEED — moving the marker up speeds things up, moving it down slows them down. (When you're trying to understand how a piece of music works, "slow it down" is almost always good advice.)

VOLUME — Moving the marker down makes the music louder, moving it up makes it softer. The left control is for the top staff and the right is for the bottom one.

SOUND — These controls let you reorchestrate your music. The left control is for the top staff and the right is for the bottom. Each can be set for any of 13 different instrumental sounds. The following names, listed from the top of the gauge to the bottom, will help you think about each instrumental sound.






- 1) harpsichord
- 2) piano
- 3) flute
- 4) organ
- 5) accordion
- 6) echo
- 7) bounce
- 8) vibrato
- 9) space case
- 10) bellows
- 11) slur
- 12) swallow
- 13) drums (Use only with treble clef to play bass drum. Add an octave raiser and place notes on highest octave for a snare drum.)

THE TIME SIGNATURE CONTROL AND BEAT COUNTER


Setting the Time Signature sets the playback scrolling speed to match the meter a piece is written in. The beat counter (next to the scissors icon) counts along as the music plays. If it finds a measure with too many or too few beats, it changes to inverse video (black number on white background).

If the beat counter changes to inverse for a measure but everything looks alright to you, start taking the measure apart a symbol at a time. Chances are you've accidentally put one symbol on top of another and the computer is doing its best to play both what you can see and what you've covered up.

THE NOTE INDICATOR




Point at a note (or space or line) and press ; the appropriate tone will sound and its name will appear in the indicator. To make the Note Indicator automatically sound a new tone and produce a new letter whenever you point at a new line or space, press . Pressing  again returns the Note Indicator to manual control (i.e. you have to press  to make it work.) When you're carrying a note, pressing  when you're in the area above and below the staves will produce a helpful line segment.



TO TRANPOSE PIECES INTO ANOTHER KEY







Pointing at the word KEY and pressing  or a button causes key names to scroll by. Pressing it again picks whichever name is visible and the computer rewrites the music to fit the new key. If you try to transpose to a key too high or low you'll hear a warning beep and the command will not be carried out. Inverse video means you're moving down the scale from your starting point; regular video, that you're moving up. Note: If you enter a key signature manually (by dragging on sharps or flats one at a time), the Key Change Control will not show the correct key signature until you use it to successfully transpose to another key.

KEYBOARD SHORTCUTS

As you gain experience with your MCS program, you'll find the keyboard helpful even in Joystick and Koala modes: Pointing where you'd like a note, rest, clef, etc. to be and pressing the appropriate key will cause it to be done.

 — 16th notes through whole notes
 — 16th rests through whole rests
 — 32nd note and 32nd rest (available only through the key board)

 — treble
 — bass clef

 — sharp
 — flat
 — natural
 — dot
 — tie
 — octave raiser

- DEL** — erases whatever's being pointed at
- SPACEBAR** — puts down another of whatever you put down last.
- U** — turns the note or tie you're carrying upside down.
- =** — scrolls forward one measure.
- A, Z, ; and :** — move hand one notch up, down, left and right
- H** sends the hand Home.
- Q** sends the hand to the quarter rest in the parts collection.
- *** — sends hand to the middle of the composing area
- P** — causes the Note Indicator to function.
- Control-S** — toggles the Note Indicator between manual and automatic.
- Control-P** — begins printing (see How to Print on this card).

IF YOU HEAR A BEEP

If you hear a beep when you try a command, one of the following is most likely happening:

1. You're trying to put in a longer piece of music than the program can handle (see manual, page 12);
2. You're trying to cut more music into the buffer than it can handle (see manual, page 4);
3. You're trying to put a note on top of a note.
4. You're trying to change to a key that would make some of the notes in your piece either too high or too low for the MCS range.
- 5) You're trying to use the Change Key Command on a song which has different key signatures in treble and bass clefs or which has some other symbol placed among the accidentals to the left of the double bar. If you want to transpose, don't put anything to the left of the double bar except sharps, flats and clefs.
6. You're trying to use the scissors to the left of the double bar. They won't work there.

HOW TO PRINT YOUR MUSIC

If you have an Atari 850 Interface Module and a parallel printer capable of graphics printing, you should be able to use your MCS program to print copies of the music you construct with it. Once you've told the program about the printer you're using (see the next paragraph) pressing **CONTROL-P** will cause it to start printing the measures on the screen at the time. After 2½ measures the printer will stop. Pressing any key will cause another 2½ measures to be printed. Press **ESC** to stop printing.

To tell your MCS program about the printer, turn on the Plug icon and press **RETURN** until the word "printer" appears on the screen. Next, look at the short list below to see if your printer is there. If it is, type the sequence next to it exactly and then press **RETURN**. If your printer isn't in the list, skip ahead to the next paragraph to learn how to find the code you need.

C-Itoh 8510 — simply press **RETURN** and the code will be entered automatically.

Okidata with Okigraph dot-addressable graphics — C???????CN???????

Epson — @AG?????M@KAA???E

(An underline means type the character while holding down the **CONTROL** key. A **@** symbol means press Escape twice for this character.)

The codes you enter tell your printer four things: 1) to do 7/72 of an inch line feeds (also called line spacing); 2) to use unidirectional print if it normally prints bidirectionally; 3) to set the vertical spacing (17 cpi, also called compressed print mode, will work best); 4) to set graphics mode to 256 dots.

When you find the codes you need in your printer manual (or get them from whoever sold you your printer) type in codes 1), 2) and 3) first. If they don't total 8 characters, add enough **?**s to bring the total to 8, then type in 4) and add enough **?**s to fill the line out to a total of 16 characters. Next, if you have an Epson printer or one which does graphics like the Epson (Most Significant Bit on top), type **E**. The press **RETURN** to complete the process. (For your information, the C-Itoh code (which the computer automatically sends if you press **RETURN** without entering anything) is @T14@>??MJ@S0257.)

Technical Note: The first 8 characters are issued to the printer only once in each printer session; the second 8 are issued before each row of graphics.

Limited Warranty

Electronic Arts warrants to the original purchaser of this computer software product that the recording medium on which the software programs are recorded will be free from defects in materials and workmanship for ninety days from the date of purchase. Defective media returned by the purchaser during that ninety day period will be replaced without charge, provided that the returned media have not been subjected to misuse, damage or excessive wear.

Following the initial ninety day warranty period, defective media will be replaced for a replacement fee of \$7.50.

Defective media should be returned to:

Electronic Arts
390 Swift Avenue
South San Francisco, CA 94080

in protective packaging, accompanied by (1) proof of purchase, (2) a brief statement describing the defect, (3) a \$7.50 check (if beyond the initial ninety day warranty period), and (4) your return address.

WHAT IS NOT COVERED BY THIS WARRANTY

THIS WARRANTY DOES NOT APPLY TO THE SOFTWARE PROGRAMS THEMSELVES. THE PROGRAMS ARE PROVIDED "AS IS."

THIS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES, WHETHER ORAL OR WRITTEN, EXPRESS OR IMPLIED. ANY IMPLIED WARRANTIES, INCLUDING IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED IN DURATION TO NINETY DAYS FROM THE DATE OF PURCHASE. ELECTRONIC ARTS SHALL NOT BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES FOR BREACH OF ANY EXPRESS OR IMPLIED WARRANTY.

Some states do not allow the exclusion or limitation of incidental or consequential damages or limitations on how long an implied warranty lasts, so the above limitation or exclusion may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. Address all correspondence to: Electronic Arts, 2755 Campus Drive, San Mateo, California 94403.

Unless identified otherwise, all programs and documentation are ©1983 Electronic Arts.