

A D D E N D U M M A N U A L

SUPER SKETCH <sup>tm</sup>

OWNER'S MANUAL ADDENDUM for Model 2350, ATARI Version

( Please keep this with your Owner's Manual )

Your SUPER SKETCH <sup>tm</sup> package (Model 2350) contains:

- 1 SUPER SKETCH<sup>tm</sup> graphics tablet
- 1 GRAPHICS MASTER<sup>tm</sup> software diskette
- 1 Owner's Manual / 1 Addendum Manual
- 1 Starter Kit with drawings to trace

PERSONAL PERIPHERALS RESERVES THE RIGHT TO MAKE IMPROVEMENTS IN THE PRODUCT DESCRIBED IN THIS MANUAL AT ANY TIME AND WITHOUT NOTICE. PERSONAL PERIPHERALS MAKES NO WARRANTIES, EITHER EXPRESSED OR IMPLIED, WITH RESPECT TO THIS MANUAL, THE PRODUCTS PACKAGING, OR WITH RESPECT TO THE SOFTWARE DESCRIBED IN THIS MANUAL, ITS QUALITY, PERFORMANCE, MERCHANITBILITY OR FITNESS FOR ANY PARTICULAR PURPOSE. THE PROGRAM IS PROVIDED "AS IS." PERSONAL PERIPHERALS MAKES CERTAIN WARRANTIES WITH REGARD TO DEFECTIVE MEDIA WHICH ARE DESCRIBED ON THE ENCLOSED WARRANTY CARD.

SUPER SKETCH developed and offered by:  
Personal Peripherals, Inc., Longview, Texas

Copyright ©1985 by Personal Peripherals Incorporated  
All Rights Reserved

## INTRODUCTION and SETTING UP

---

Personal Peripherals, Inc. is glad to bring you the new cost-reduced version of the ATARI Super SKetch. This sheet has been added to reflect the manual revisions required for the new start-up procedures not covered in your owner's manual.

Setting up to draw with the SUPER SKETCH Model 2350 is very simple. The equipment required is your Atari computer, a disk drive, and a color TV set or monitor. You may leave other peripherals such as your printer, connected as usual. The box that holds your SUPER SKETCH tablet may be used as a storage tray when it is not in use.

With your computer turned off, plug the cord from the SUPER SKETCH tablet into the first joystick port. Then turn on the disk drive and place your GRAPHICS MASTER software diskette into the drive. The diskette is not copy-protected for your convenience. Be sure to make a back-up of your diskette before using it. It is recommended that you store your original diskette and work from the back-up.

Before you turn on the computer, first make sure that there is no software cartridge plugged into the game slot(s). If you own one of the "XL" or "XE" series of ATARI computers, press and hold down the OPTION key while you are turning on the computer. When you turn on the power switch, the system will automatically load and start the GRAPHICS MASTER software. When the title screen appears, release the OPTION key.

The software will want to calibrate the tablet at this time. The title screen instructs you to place the control arm in the lower-right hand corner of the pad before you press the MENU key. When the MENU key is pressed, the pad will be read and calibrated. After this the program will automatically switch into the main menu mode as discussed in your owner's manual.

We at Personal Peripherals hope you enjoy your Super Sketch. If you have any suggestions or comments, please feel free to write to the address below. Should your disk fail for any reason, send it and \$7.50 (which includes postage and handling) to the address below. We will send you a new one.

PERSONAL PERIPHERALS, INC.  
1505 S. Green St.  
Longview, Texas 75602