SMART 1030

QUICK REFERENCE CARD

LIST OF COMMANDS

PREFIXES		DESCRIPTION
AT		Attention command which precedes all other commands.
A/		Repeat the last command. Does not require use of AT command.
COMMAND	PARAMETERS	DESCRIPTION
	TATAMETER	DESCRIPTION
A	NONE	Answer phone in answer mode without waiting for any rings.
В	NONE	Access the bulletin board data base and display listing on screen.
Bx	x=AZ	Dial the phone number of the bulletin board selected.
Dx	x=09TPR,;	Dial a phone number. T=Touch-Tone P=Pulse dial R=Switches modem to answer mode ,=Pause ;=Return to local command state
Ex	x=01	x=1 Echo back all characters in command statex=0 Do not echo back characters
Gx	x=01	x=1 ATARI ASCII x=0 ASCII
Hx	x=01	x=1 Off-hook x=0 On-hook
0	NONE	Return to the on-line state.
Р	NONE	Pulse dialing.

SMART 1030

QUICK REFERENCE CARD

LIST OF COMMANDS

COMMAND	PARAMETERS	DESCRIPTIONS
Qx	x=01	x=1 Quiet mode, no result codes sent x=0 Result codes sent.
R	NONE	Switches modem to answer mode.
Т	NONE	Touch-Tone dialing.
Vx	x=01	x=1 Result codes will be numeric x=0 Result codes will be numeric
Z	NONE	Initialize and reset the modem.

RESULT CODES

NUMERIC	ENGLISH	MEANING
0	ОК	The command has been executed normally.
1	CONNECT	A carrier has been detected.
2	RING	The phone is ringing.
3	NO CARRIER	Carrier was lost or never detected.
4	ERROR	An error exists in the command line.

COPYRIGHT 1985
E & B COMPUTER SERVICES
P.O. BOX 292506
COLUMBUS, OHIO 43229